

Beauty America World

8L / 20L Towel Warmer with UV Light Sterilizer

Model # KDJ-080 / KDJ-200



KDJ-080



KDJ-200

Thank you for choosing our products

Please read the "Usage Instructions" before use.

This UV towel warmer can be used for heating & sterilization using the Ultraviolet function.

TECHNICAL INFORMATION

Model	Dimensions (mm)			Volt (V)	Frequency (Hz)	Power (W)		Temperatures (°C)	Capacity (L)	Weight (kg)
	L	W	L			Heating	sterilization			
KDJ-080	320	270	270	120	60	130	3	75±10	8	4.5
KDJ-200	450	333	335	120	60	200	3	75±10	20	8

- Wave length of ultraviolet ray: $\lambda = 253.7\text{mm}$
- Strengths of 1m ultraviolet ray: $20\text{uw}/\text{cm}^2$
- Wave length of ultraviolet =185mm
- Power of ultraviolet ray lamp: <3W
- Service life of ultraviolet: 8000h
- Rate of sterilization: 99.9%

Beauty America World

8L / 20L Towel Warmer with UV Light Sterilizer

Model # KDJ-080 / KDJ-200

USAGE INSTRUCTIONS

1. Place and keep the machine in a dry place with good ventilation.
2. Make sure that the machine is firmly settled on a smooth surface before opening the door or turning on the machine.
3. Only qualified power supply can be used. Insert power plug into qualified power socket.
4. Only clean and tidily rolled towels or tools can be put into cabinet, to be placed carefully on shelf. Do not overcrowd.
5. Close the door after correctly following the procedures and turn on the cabinet.
6. Process: Sterilize first then keep warm. Press the UV switch to disinfection with the blue indicator on, showing that the cabinet is in disinfect mode.
7. Press the power switch with the red indicator on, showing that the cabinet is in auto constant warming mode at the temperature setup of 75°C.
8. The time required for towels to reach the desired temperature may vary due to the different starting temperature of towels.
9. Power plug should be unplugged from power socket if the machine is not used.
10. UV disinfection shall be done manually to control the disinfection period by the user, recommended to be 25 minutes.
11. As a safety protection, the UV lamp will not work until the door is closed firmly. If the door is opened while sterilizing, the UV lamp will stop function, until the door is closed firmly again.

WARNINGS

1. The power socket used should meet the safety requirement for electricity with proper grounding.
If not sure, DO NOT USE.
2. Non-professionals are forbidden to disassemble ultraviolet sterilizing cupboard. There is no part you can repair.
3. Do not open the door of the cabinet during disinfection or warming, otherwise it may adversely affect the disinfection and warming effects. Use tongs to pick up the articles in the heated cabinet. Do not use your hands; otherwise it may cause contamination and scalding.
4. Unplug power plug before cleaning.
5. Regularly check the water collector to remove water accumulated.
6. Only place used and clean towels into cabinet. Do not overcrowd.
7. Please do not use cabinet as a storage tool. Towels which are left in the cabinet for 24 hours or more may begin to smell. In that case, wash the towels first before placing them in the cabinet for sterilization.
8. In case of damaged power cord or other malfunctions, return to manufacturer for professional repair.
9. Attempting repair will VOID WARRANTY.

PROHIBITED

It is prohibited to use this machine outdoors or in high temperature or in places with poor ventilation.
It is prohibited to use in rain, or moist places.

Imported by B&S Beauty Supply
www.bns-beautysupply.com
info@bns-beautysupply.com